How to Fix the Canon B200 Printer Error

Undoubtedly, Canon printers are one of the top quality printers available in the market but It can be terrifying to go through Canon B200 Printer Error. Most users take it as a sign that the time for buying a new printer has arrived. Although witnessing this error can be highly frustrating, there are a few solutions which you can try before you think of buying a new printer.This step-by-step tutorial will teach you five different approaches to resolve the Canon printer problem B200. Since many Canon printers exhibit this problem, you will need to modify these fixes for your printer. However, if you follow our instructions exactly as they are stated, fixing this problem will be very straightforward and easy.

Following are the ways to to Fix the Canon B200 Printer Error:-

Solution 1: Reset Print Head.

- First, Unplug the canon printer.
- You should open the printer cover so that you can view the print head and then slide the print head to the centre.
- Without covering the printer, replug the print head of the printer and the print head will start to move.
- Close the cover as the printer head starts moving to the left.
- At last, Wait till the Printer gets reboot.

Solution 2: Removing Obstructions.

- Take out the ink tanks by opening the Printer.
- Now, lift-up the locking part.
- Now, take out the print head from the carriage unit.

- Put the print head back and lock the lever.
- Place ink tanks at their place and close the printer cover.
- Turn off and unplug the printer.
- Restart the printer after 5-10 minutes.

Solution 3: Cleaning Print Head

- Take out the cartridges by unplugging the printer.
- Take out the print head and clean it using pure alcohol. Shake occasionally.
- You should clean the connectors which connect the print head to the printer. You can clean with Alcohol.
- After drying the print head for an hour, reconnect it to the printer along with cartridges.
- Slide the print head to the left.
- Re-plug your printer.
- Put the printer cover down and turn on the printer.

Solution 4: Removing Old Ink

- Switch off the printer and take out cartridges.
- Place the print head under hot water until the water which is coming out is completely clean.
- Take a towel and dry the print head and leave it for one hour.
- Reinsert the print head into the printer.
- Restart the printer.

Solution 5: Checking Paper Jam

- Turn off the printer.
- Unplug the printer for nearly 10 minutes.
- Now, take out a paper out of the printer.
- Check carefully if there is any jam or obstruction in the Printer.
- If you find nothing, then you should re-plug and then restart the printer.

Conclusion

If nothing works for you, The last solution is to Take out the Canon software CD that comes with your printer and reload the printer driver. If your Canon printer still displays Fault B200 even after a reinstalling driver, it's likely a genuine error, and you should start shopping for a new printer.

Read More information Click the link which is given below : ij.start.canon| Canon Printer Drivers| ij.start.canon|

Keywords -
#how_**do_i**_fix_the_b200_error_**on_my**_canon_printer , #ij_start_cannon_ij_start_canon , #Canon_printer_drivers ,

#**what_is**_b200_error_**on**_canon_printer,

#canon_b200_error_**lawsuit,**

#canon_b200_**reset_tool,**

#canon_**mg5220**_b200_error,

#canon_**mp560**_b200_error,

#canon_**pro_100**_b200_error,

#canon_b200_**hack**